AndyMark 4" Plaction Wheel (am-0198) Assembly Instructions

June 2012

Parts needed to make a 4" Plaction Wheel:

Component	Qty.	Part #
4" Plaction Wheel Halves	2	N/A
#10-32 x 1.5" SHCS	6	am-1014
#10-32 Nylock Nuts	6	am-1042

Tool needed:

³/₁₆" Allen wrench



4" Plaction Wheel Assembly Instructions:

<u>Step 1:</u> Snap together the two 4" plaction wheel halves, making sure the pins are aligning to their proper slots.

<u>Step 2:</u> Insert the six #10-32 Nylock Nuts into the designated holes. Place your hand over that wheel halve so it covers the #10-32 Nylock Nuts. Turn it over.



Step 3: Insert the #10-32 x 1.5" SHCS one by one, and tighten them as you do so.



The 4" plaction wheel should look like this once complete.





For more information on our products, please visit us on our website, www.andymark.com.