

# AndyMark 8" Plaction Wheel (am-0512) Assembly Instructions

June 2012



Parts needed to make an 8" Plaction Wheel:

Tool needed:

Component	Qty.	Part #
8" Plaction Wheel Halves	2	N/A
#10-32 x 1" SHCS	6	am-1056
#10-32 Nylock Nuts	6	am-1042

$\frac{3}{16}$ " Allen wrench

## 8" Plaction Wheel Assembly Instructions:

Step 1: Snap the two 8" Plaction wheel halves together, aligning the pins to their appropriate slots.



Step 2: Place a #10-32 Nylock Nut into one of the outer holes. Insert and tighten a #10-32 x 1" SHCS to that #10-32 Nylock Nut.



Step 3: Repeat step 2 until all the outer holes have a #10-32 Nylock Nut with its corresponding #10-32 x 1" SHCS.

